


CONN6
USB Plug Type A

Host

Chipflasher

CONN7
USB Plug Type A

CONN8
USB Plug Type A



Y-USB Power Cable

Zerocat Chipflasher

Flash free firmware, kick the Management Engine.
[git://zerocat.org/zerocat/projects/chipflasher](https://zerocat.org/zerocat/projects/chipflasher)

TITLE

FILE:

testboard-page12.sch

REVISION:

v2.0.2-0-4270742b1

PAGE

OF

DRAWN BY:

kmx